

Remote Indicating Lamp

**FIRE
ALARM
SYSTEMS**



HC-200LA

Remote Indicating Lamp

Model	HC-200LA
Voltage	2VDC
Current	20mA
Size	119mm X 72mm X 28mm
<p>Super bright LED (red light) Connect with smoke detector or heat detector directly instead of connecting with Fire Alarm Control Panel, easy and conveniently install. When smoke detector or heat detector alarm, it will light up in the remote area to indicate which detector alarm.</p>	



HC-200LB

Remote Indicating Lamp

Model	HC-200LB
Voltage	2VDC
Current	20mA
Size	86mm X 86mm X 23mm
<p>Super bright LED (red light) Connect with smoke detector or heat detector directly instead of connecting with Fire Alarm Control Panel, easy and conveniently install. When smoke detector or heat detector alarm, it will light up in the remote area to indicate which detector alarm.</p>	

(-R) function :

Connect a Remote Indicating Lamp

Detector has (-R) contact to connect a **Remote Indicating Lamp** to show Detector's fire signal at another place.




Fig 1. for **ONE** Detector to connect a **Remote Indicating Lamp**.




Fig 2. for **TWO** Detectors or **MORE** to connect a common **Remote Indicating Lamp**.